

Pull Out Desk

Assembly Instructions - please keep for future reference

0000000



Dimensions

Width - 105,0cm

Depth - 70,0cm

Height - 68,1cm

Important- Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customers Helpline: 0844 8008475



Instructions for use

IMPORTANT, READ CAREFULLY- RETAIN FOR FUTURE REFERENCE

WARNING: This product is suitable for children above the age of 6 years old. Before starting assembly:

- *Do not use this item if any structural part is broken or missing.
- *Check you have all the components and tools listed.
- *Remove all fittings from the plastic bags and separate them into their groups.
- *Keep children and animals from the work area, small parts could *This furniture meets the choke if swallowed.

- *Make sure you have enough space to lay out the parts before starting.
- *Assemble the items as close to its final position (in the same room) as possible.
- *Assemble on the soft level surface to avoid damaging the unit or your floor.
- european standard certification BS 4875-7:2006, FRQG C001:2008 & FRQG C004:2008



We do not reccomend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand scredrivers.

- *Dispose of all packaging carefully and responsibly.
- *Assembly should be carried out by competent adult only.

Care and maintenance:

- * Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- *Regularly check all fastenings to ensure that they properly tightened.

*Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to the heat sources such as radiators of fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.


Wall Fixing (if required)



Wood


Brick or Masonary







Cavity wall Special toggle wall plugs are needed. Seek expert advice.

If fixing to wood make sure that Use an appropriate wall plug it isn't chipboard as screws can provided you are soure your wall easily pull away. is sound.





Components- Panels
Please check that you have the panels listed below





Components- Fittings Please check that you have the fittings listed below







Step 3

In this step use these fittings:

B x2

C x6
Front slat place in partiton panel. Place eccentric bolts B in Pull Out Desk shelf 3
Assemble partition panal 5. Push partition shelf 3, base 4 and panel 5 together and insert locking nut C. Lock using Phillips head screwdriver.







Step 4


In this step use these fittings:


C x6


Assemble fixed shelf Push back panel 2, together, insert locking nuts C.











Customer Service Form

Please return co	mplete to	Fax: 0560 1132071	
Name:			
· ·			
Date of purchase	9 :		
Place of purchas	se:		
Product Name:			
Problem:			
Parts Needed:	Part No.	Quantity	Description
Please quote assembly instruction or number	3 <u>.</u>		e.g drawer base