

STEP BY STEP INSTRUCTIONSGORILLA TRAINING GOAL

STEP 1

Roll out Gorilla Goal where you are going to use it and onto a level surface



STEP 2

Make sure the net is not caught on the hose or connectors.



STEP 3

Using the pump provided (and only this pump) attach to valve situated at the side of the goal (rear of cantilever on larger sizes) making sure that the valve is turned fully anti-clockwise.



TIP: The pump provided will only allow the goal to inflate to required pressure.

STEP 4

Attach the other end of the pump hose to the INFLATE position on the pump handle. Put feet on the foot plates on either side of the pump for stability.



TIP: You do not need trainers or sports footwear for this - high heels work ok!

STEP 5

Inflate for approx. 20-30 pumps (under normal circumstances) and screw the valve cap back on tight after inflation.



TIP: Long slow pumps are more effective than trying to go fast.

STEP 6

Pop up the Gorilla Training Goal into an upright position. On larger sizes it may be necessary for 2 people to carry out stage 6.



TIP: Make sure pump is not still attached to valve when popping up goal into position.

STEP 7

Ensure that the Gorilla Training Goal is secured at all times by means of the appropriate supplied anchor system.



TIP: On larger sizes the rear cantilever needs to be secured to stop the goal tipping forward.

STEP 8

If fixing on grass - please use the ground pegs provided attach pegs provided at front and back of both side returns. On larger sizes with cantilever - place 2 pegs overlapped over each black cantilever.



TIP: If ground is hard or stony it may be better to use the sandbags.

T: 01635 517560

E: info@phoenixsportinggoods.com

W: www.phoenixsportinggoods.com





STEP BY STEP INSTRUCTIONS **GORILLA TRAINING GOAL**

STEP 9

If fixing on other surfaces i.e. Astroturf, concrete or inside please use bags provided which should be fully filled with soft sand to ensure even distribution of weight - place the sandbags over both side returns.



TIP: Place sandbags with ties on outside of net.

STEP 10

Once in position add more air using pump provided to pressure required. TIP: If the goal is in the same position for long periods or in hot weather it may be necessary to check pressure periodically.



TIP: If the goal is in position for long periods or in hot weather it be necessary to check pressure periodically.

STEP 11

After use make sure the area is clear of all obstacles and people before deflation.



STEP 12

To deflate the goal - push the valve in and twist fully clockwise - the goal will fall to the ground.



STEP 13

Remove all pegs or sandbags after deflation.



TIP: The goal will fall the way it needs to be packed.

STEP 14

To aid packing, remove hose from pump & re-attach to the deflate position on the pump handle. Re-attach the other end of the hose to the goal with valve turned fully clockwise & pump several times to remove any residual air.



TIP: When all air has been removed & you can't pump anymore - stop.

STEP 15

Place the goal on the roll-out section of the bag with valve turned fully to the left and with the valve cap replaced.



TIP: Note point 13 - do not fold the goal - arrange as the goal falls to floor shuffling along roll-out section - this will help when next using the goal.

STEP 16

Carefully roll the goal back into bag, put pump on top of the roll-out section, close top zippers first, then side zippers after any protruding parts are back inside the bag.



TIP: There is no ongoing maintenance, subject to product not being misused. Following these instructions will greatly help your future enjoyment of your goal.

Warning

- > Never drag the inflated/deflated goal on hard ground as it will damage the goal.
- > Make sure you suck out the residual air with pump before rolling goal back into the bag.
- > Do not expose to chemicals, such as thinner, gasoline & acetone.
- > Do not use the goal when it is frozen.
- > Do not leave the goal outdoors permanently.

Important

> Looking after your goal by following these simple instructions will help to maintain the quality of the goal.

T: 01635 517560

E: info@phoenixsportinggoods.com





INSTRUCTIONS, WARRANTY AND WARNINGS GORILLA GOALS

Instructions for Use

Setting up the Gorilla Goal

- Upon receipt of your Gorilla goal, please check all components are present (inflatable structure, ground anchors, sandbags, pump and instruction leaflet).
- Carry the bag to the site of use and remove the components.
- Unpack and separate all items from the carry bag and unfold the inflatable structure.
- Attach pump hose to the inflate position on the pump handle.
- Depress the moveable centre piece of the valve on the goal and ensure it is turned fully anti-clockwise.
- Attach the end of the pump hose to the valve on the goal structure.
- Inflate the structure until rigid, ensuring the net isn't caught on the net clips throughout inflation.
- Stand the inflated stanchion into the appropriate position then secure with ground pegs for soft surfaces or sand bags for hard surfaces.

Packing the Inflatable Gorilla Goal Away

- Reverse of previous steps, depressing and turning the valve centre piece fully clockwise and using the deflate option on the pump to remove residual air.
- Unroll the bag inlay and lay the deflated structure along the length of it, with the end furthest from the bag tucked into the small pocked.
- Firmly roll the structure back towards the bag.
- Once the goal is in the main bag compartment zip up the front, add back all of the other components then zip and velcro the top of the bag shut.

<u>General</u>

- The Gorilla Goal is a portable, inflatable structure and is expected to stand without significant loss of pressure for up to 8 hrs of continuous use. It is not a permanent structure and should not be expected to remain inflated indefinitely.
- Ensure that the net does not become tangled in the net clips during inflation as this will stop the structure holding the correct shape.
- Always remove residual air after use with deflation option on pump.

Warning

• It is the user's responsibility to undertake location specific risk assessments to assess any potential hazards, such as trips etc. and to ensure that the equipment provided is used to minimise any potential hazards. No responsibility will be accepted by Phoenix Sporting Goods Ltd for any injury arising from the use of this product.



INSTRUCTIONS, WARRANTY AND WARNINGS GORILLA GOALS

Gorilla Goals are guaranteed for 24 months from the date of purchase against faulty materials or workmanship. During this period they will be replaced free of charge provided that:

- The product is returned to place of purchase with evidence of purchase in accordance with the claims procedure outlined below.
- The product has been purchased by the user and not via another third party nor used for hire purposes.
- The product has been used in accordance with instructions provided with product at time of purchase and not outside warranty guidance.
- The product must not have been misused or handled carelessly, or by ignoring the warnings included with the instructions.
- Repairs have not been attempted with anything other than product specific kit.
- Inflatable structures are only guaranteed for periods of use up to 8 hours.

Claims Procedure

Any claim made under this guarantee should be made directly to the place of purchase where the product was purchased. The claim itself should ideally be made in writing together with the date and place of purchase, and giving a brief explanation of the problem, and circumstances which have led to the claim.

PLEASE NOTE that it is essential that the claim reaches the place of purchase within 14 days of the last day of this Guarantee. Late claims will not be considered. This Guarantee applies to all Gorilla Goals goods purchased from an authorised reseller of Phoenix Sporting Goods Ltd.

This Guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This Guarantee is offered as an extra benefit and does not affect your statutory rights as a consumer.

Returns

Your statutory right to a 14 day return applies, providing product is returned in original packaging and in a fully re-saleable condition. If any signs of wear are visible then a full refund will NOT be given.

If product is found to be unsaleable due to neglect or misuse then no refund will be offered.

For enquiries please contact your re-seller or sales@phoenixsportinggoods.com (if purchased directly).